

Sony-Ericsson T616 phone driver

Use the Sony-Ericsson T616 phone driver to establish a connection between your Tapwave™ Zodiac™ console and your Sony-Ericsson T616 Bluetooth-enabled phone. Tapwave can NOT assist you with configuring your GSM or GPRS connection. For assistance configuring your GSM or GPRS connection, contact your cellular service provider.

Installation Instructions for Windows Users

1. Download the Sony-ET616TW.prc. Be sure to note the location of the directory/folder the file is extracted to.
2. Double-click the Sony-ET616TW.prc to launch the Install tool in Palm Desktop
3. Select the correct user name for the Zodiac you are installing to from the User list.
4. Select OK.
5. During the next HotSync synchronization, the Sony-Ericsson T616 Phone Driver will be installed and activated.
6. After installation you will be prompted to reset your Zodiac console to use the driver.

Instructions for pairing the Zodiac and Sony-Ericsson T616 phone via Bluetooth

Settings on the Phone:

1. On the Sony-Ericsson T616, ensure the Bluetooth radio is turned on and ready to accept a Bluetooth connection:
 1. From the main screen, Scroll to CONNECT then press SELECT.
 2. Select Bluetooth, press SELECT.
 3. Select Turn On, press SELECT.
 4. Select OPTIONS, press SELECT.
 5. Select VISIBILITY, press SELECT.
 6. Select SHOW PHONE, press SELECT.
 7. Press the back button to get back to the Main Menu.
 8. The phone will now wait for the Zodiac to initiate pairing.

Settings on the Zodiac:

1. Go to Prefs.
2. Go to Connections Panel.
3. Highlight the BT to Sony-E T616 connection and Tap Edit.
4. Select the Sony-Ericsson T616 from the list.
5. Select Device: Tap to Find.
6. When prompted "Add to trusted device list" press YES.
7. When prompted for a passkey, enter anything you like.
8. Select OK.
9. On the phone you will be prompted to enter a corresponding passkey.
10. Enter the same passkey as on the Zodiac and select OK.

You will receive a confirmation dialog on the Zodiac asking if you would like this to be the default connection for your phone applications. Choose yes if this is the phone you will use most often.