Sony-Ericsson T68i phone driver

Use the Sony-Ericsson T68i phone driver to establish a connection between your Tapwave™ Zodiac™ console and your Sony-Ericsson T68i Bluetooth-enabled phone. Tapwave can NOT assist you with configuring your GSM or GPRS connection. For assistance configuring your GSM or GPRS connection, contact your cellular service provider.

Installation Instructions for Windows Users

1. Download the Sony-ET68iTW.prc. Be sure to note the location of the directory/folder the file is extracted to.
2. Double-click the Sony-ET68iTW.prc to launch the Install tool in Palm Desktop.
3. Select the correct user name for the Zodiac you are installing to from the User list.
4. Select OK.
5. During the next HotSync synchronization, the Sony-Ericsson T68i Phone Driver will be installed and activated.
6. After installation you will be prompted to reset your Zodiac console to use the driver.

Instructions for pairing the Zodiac and Sony-Ericsson T68i phone via Bluetooth

Settings on the Phone:

1. On the Sony-Ericsson T68i, ensure the Bluetooth radio is turned on and ready to accept a Bluetooth connection:
1. From the main screen, Scroll to CONNECT then press Yes.
2. Select (3)Bluetooth, press Yes.
3. Select (4) Options, press Yes.
4. Select (1) Operations mode, press Yes.
5. Select ON, press Yes.
6. Press No to back out to Bluetooth Menu.
7. Select (2)Linked Devices, press Yes.
8. Select Add Device, Yes.
9. Select Phone Accepts, Yes.
10. The phone will now wait for the Zodiac to initiate pairing.

Settings on the Zodiac:

1. Go to Prefs.
2. Go to Connections Panel.
3. Highlight the BT to Sony-E T68i connection and Tap Edit.
4. Select the Sony-Ericsson T68i from the Model list.
5. Select Device: Tap to Find.
6. When prompted add to trusted device list press YES.
7. When prompted for a passkey, enter anything you like.
8. Select OK.
9. On the phone you will be prompted to enter a corresponding passkey.
10. Enter the same passkey as on the Zodiac and select OK.

You will receive a confirmation dialog on your Zodiac asking if you would like this to be the default connection for your phone applications. Choose yes if this is the phone you will use most often.